

Business Mobility (IP) DECT

DECT 1766 Handset

Basic User Guide







Date: October 2015

Great care has been taken to ensure that the information contained in this handbook is accurate and complete. Should any errors or omissions be discovered or should any user wish to make a suggestion for improving this handbook, they are invited to send the relevant details to:

> NEC Nederland B.V. P.O. BOX 32 1200 JD HILVERSUM THE NETHERLANDS

All right are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner. All brand names and product names in this document are trademarks or registered trademarks of their respective companies.

Disclaimer

NEC reserves the right to revise or make changes or improvements to the products described in the user manual or to this user manual itself at any time without obligation to notify any person of such revision or improvements.

Revision history

Revision history

October, 2015

Creation of this Basic User Manual.

Disclaimer	3
Revision history	4
Contents	5
Introduction	10
Notice on the use of the handsets	10
Getting started	11
Installing the battery pack Installing the charger Charging the batteries Charging a spare battery Charging guidelines Charging and operating times Charge display Handset keys and display areas Handset keys Display Icon line Time & Date area Dialogue area Idle mode Call mode Dialogue mode Menu mode Edit mode Soft key line	11 12 12 13 14 15 17 18 19 19 19
Used notation in this manual	
General functions	
Switching the handset on	27 27 27

Make a call	28
Dialling a number	
Using Predial mode	28
Using Central or Private Directory	28
Using Speed dial	29
Making an emergency SOS call	
Making an emergency Mandown call	
Making an emergency Pull Cord call	
Answering a call	29
Answering a call in Normal mode	
Answering a call using any key	
Auto-answering mode	30
Muting the ringer of an incoming call	
Rejecting an incoming call	
Change settings during a call	
Adjusting the headset or loudspeaker volume	
Using mute during a call	
Deactivate the microphone (mute)	
Activate the microphone (unmute)	
Activate and deactivate the loudspeaker (toggle function)	
Transferring a call	
Dialling second destination then transfer	
Using Private or Central Directory then transfer	
Calls list	33
Actions on the calls lists	34
Open Calls list	
Checking the details of a call	34
Dialling the number of the call list entry	
First edit then dial the number of the call list entry	
Transferring a name/number to your contacts list	35
Add a number to an existing contact	37
Transferring a number to the caller filter list	
Deleting an entry	38
Missed calls list entries will also be deleted from the list if	
Deleting all entries	39
Contacts	40
Adding a new contact	40
Changing information of a contact	
Deleting a contact	
Deleting all contacts	42

Speed dial feature	
Adding, replacing or deleting a speed dial contact	
Adding contact to the caller filter list	
Messaging	45
Normal, urgent and emergency messages	45
Normal messages	
Urgent messages	
Emergency messages	
Confirming receipts	
Message list full	46
Message Menu Sections	
Open Message menu section	
Actions on the messages	47
Reading a message	47
Writing and saving a new/draft message	48
Writing and sending a new/draft message	
Forwarding a message	
Replying to an incoming message	
Deleting a message	
Deleting all messages Saving sender to the contacts list	
Add sender to the contacts list	
Message settings	
Calendar	ວວ
Open the Calendar	55
Changing the calendar format (week or month view)	55
Open schedule for today	
Open schedule for a given date	
Adding an appointment Open appointment	
Editing an appointment	
Copying an appointment	
Deleting an appointment	
Additional features (Accessories)	
Calculator	
Stopwatch	61
Alarms (alarm clock)	
Open Alarms	
Assigning or change a daily alarm	62

Turning off a daily alarm	62
Assigning or change a recurrent alarm	
Turning off a recurrent alarm	63
Setting snooze time	
Telephone settings	65
Open Settings menu section	65
General settings	66
Setting Silent	
Setting the time and date	
Setting the time	
Setting the date	
Setting the language	
Configuring shortcuts	
Configuring the LED signal	
Security options	72
Setting the Phone lock feature	
Setting the Automatic keypad lock feature	73
Changing the PIN code	
Changing the Proxy password	74
Defining the handset name	73
Setting the RFID notification feature	
Assigning an RFID destination number	
Setting the RFID Out of LF feature	77
Resetting settings	
View status information	
Sounds (normal & silent) settings	
Incoming call	
Setting the ring volume	81
Setting the ring melodies	
Setting the increasing ring feature	82
Setting the vibrator feature	
Message notifications	83
Setting the notification volume	
Setting the notification melodies	84
Setting the increasing notification feature	84
Setting the vibrator feature	
Alerts	
Setting the alert volume	
Setting the alert melody	86
Setting the increasing alert feature	87
Setting the vibrator feature	
Feedback	
Setting the key sound feature	
Setting confirmation sound	88

Setting the coverage warning feature	89
Setting the charger warning feature	
Noise Reduction	90
Setting the noise reduction feature	90
Display settings	91
Selecting Wallpaper	91
Selecting startup screen	91
Configuring power save	
Calls settings	
View statistics information	
Answer mode configuration	
Caller filter configuration	
Adding an entry to the Caller filter list	90
Changing a Caller filter entry	90 98
Deleting an entry from the Caller filter list	99
Deleting all entries in the Caller filter list	99
Activating Caller filter	
Configuring emergency or SOS calls	101
Assigning emergency call number	101
Assigning an emergency message	103
Configuring Mandown calls	103
Activating Mandown and assigning a call number	103
Assigning Mandown and assigning a message	105
Setting the Mandown Auto Answer option	108
Setting the Mandown Delay and Prealarm Time	108
Configuring Pull Cord calls	109
Activating Pull Cord and assigning a call number	109
Assigning Pull Cord and assigning a message Setting the Pull Cord Auto Answer option	117
Setting the Pull Cord Delay and Prealarm Time	114
Assigning the Silent charging feature	115
Defining the missed call time	116
Voicemail	
Assigning the Voicemail number	
Connectivity settings	118
DECT system selection	
Bluetooth	
Enable Bluetooth	
Disable Bluetooth	
Pairing Bluetooth headset	
Connecting a paired Bluetooth headset	
Disconnecting a paired Bluetooth headset	
Rename a Bluetooth headset	122
Retrieve Information Bluetooth headset	
Delete Bluetooth headset	124
Delete All Bluetooth headsets	125

Introduction

Introduction

Also refer to the following documents:

- General DECT Handset Information Guide
- I766 Quick Reference Guide

Notice on the use of the handsets

Like all cordless telephones, the I766 DECT handset uses radio signals, which do not guarantee a connection under all circumstances. Do not rely exclusively on the DECT handsets when making indispensable calls (such as medical emergencies).

Man down feature

The man down feature of the I766 does not replace companion supervision by a colleague or other people. In case of critical, emergency or life-threatening situations make sure that other persons are present or that appropriate measures are taken.

The functionality of the man down alarm is based on a horizontal handset position. Situations can occur in which the end-user requires help, but the man down alarm is not activated, because e.g. the set itself is not in the horizontal position, the wireless connections are interrupted or radio coverage in the environment where the man down alarm is being used, is not sufficient.

Pull cord and SOS functions

The Pull cord and SOS functions of the I766 do not replace companion supervision by a colleague or other people. In case of critical, emergency or life-threatening situations make sure that other persons are present or that appropriate measures are taken.

Installing the battery pack

- 1. Place the handset face down on a flat surface.
- 2. Slide the lock at the bottom of the battery compartment cover upwards and at the same time lift the cover away from the handset.
- 3. Remove the battery compartment cover.
- 4. Push the battery pack into the casing.
- 5. Replace the battery cover.

Installing the charger

- 1. Place the charger on a flat surface.
- 2. Connect the micro-B USB connector of the USB cable to (the back of) the charger.
- 3. Connect the type A USB connector to the USB AC/DC Adapter.
- 4. Connect the adapter to an electrical outlet.
- 5. Place the handset on the charger as shown in Figure 1.



Figure 1: I766 in Desktop Charger

Charging the batteries

Place the handset in the charger as shown in <u>Figure 1</u>. For a few seconds the display of the handset shows:



Figure 2: Battery charging display

	The handset, if switched off, automatically switches on when placed in the charger.
--	---

Charging a spare battery

The I766 Desktop Charger can be used to charge a spare battery pack for the I766. To charge a spare battery pack:

- 1. Place the spare battery pack in the spare battery charging slot compartment. (Upside down and with text on the battery pack facing to the front.)
- 2. Slide the spare battery pack under the plastic holder to keep it in place.

Charging guidelines

Please read the concerning section in the DECT Handsets – General Information Guide carefully!

Charging and operating times

Discharged batteries require 7 hours (using the spare battery slot might take longer) to completely recharge. Completely charged batteries provide the handset with up to 16 hours of talk time and 160 hours of standby time.

Charge display

The battery charge status appears on the top of the display screen:

Table 1: Battery charge status icons

Icon	Charge status
	Almost empty
	Less than 10%
=	10% to 20%
	20% to 90% (the bigger the green bar, the higher the charged percentage)
	Fully charged (more than 90%)

When the battery is nearly discharged a warning beep sounds and, when not in a call, the display shows:



Figure 3: Battery low display

You cannot make calls while this message appears.

Handset keys and display areas



Figure 4: Elements of the I766 (Front View)



Figure 5: Elements of the I766 (Side Views)

Handset keys

Table 2: Keys of the Handset

Key		Description
LEFT SOFT KEY	1	Key related to the action given on the bottom left of the display.
MIDDLE SOFT KEY	1	Key related to the action given on the bottom middle of the display.
RIGHT SOFT KEY	1	Key related to the action given on the bottom right of the display.
UP		Use the navigation keys to: - Select the required menu icon or menu element;
DOWN		 Navigate the cursor; In some cases change (increase/decrease) a given
LEFT		value; - Access the shortcut assigned to it.
RIGHT		
OK		Used to acknowledge menu selection.
CALL	R [Used to go off hook and to initiate enquiry/hold/shuttle.
CLR	•	Use the Clear key to Release a call;

Table 2: Keys of the Handset

Key		Description
		 Return to the previous step in a menu; Switch your handset off (long press) Switch your handset on.
SPEAKER	В	Used to go off hook and initiate enquiry using hands free.
MENU	ļII	Used to access main menu items.
sos		Long press the SOS key to make an emergency call (if configured).
VOLUME UP	+	To increase the handset volume.
VOLUME DOWN	ı	Decrease the handset volume.
1–9	1 ap	Use 1 – 9 to Insert a digit in a number; Insert a character; Select a Speed dial number
0	0	Use 0 to - Insert a 0 in a number; - Insert a character.




Table 2: Keys of the Handset

Key		Description
#	#	Use # to - Insert a # in a number; - Switch between Normal and Silent (sounds & alerts) settings by long pressing (more than 2 seconds) the key. - Toggle the character case (capital, lower case or digit) when in edit mode.
LINE KEY		Use one of the four Line keys to - Select a Speed dial number - Access the shortcut assigned to it.

Display

Figure 6 shows the four areas of the display:

- Icon line
- Time & Date area
- Dialogue area
- Soft key line



Figure 6: Display screen

Icon line

The icon line displays the status of the handset.

Table 3: Icon line icons

Icon	Description
11	Level of radio signal (always shown)
=	New text message received
⊠ 6	Voice message waiting indication
	Keypad locked
•	Alarm set
œ	Missed calls
U	Ring
*	Ringer deactivated
Ų	Caller filter active

	Getting started
4	Pull cord activated
4	USB connected
-	Battery charge status Refer to <u>Table 1</u> for Battery status icons.

Time & Date area

The Time & Date area is only shown in Idle mode and gives the current time and date. In any other mode this part of the display is added to the Dialogue area (see next).

Dialogue area

The Dialogue area displays information according to the operational mode of the handset:

Idle mode

In Idle mode, the dialogue area displays information like DECT system name, handset's DNR, and so on.



Figure 7: Idle mode screen

Call mode

In Call mode, the dialogue area displays information related to the call, like number and name of the calling/connected party and some status icons (see Table 4 and Table 5).

Table 4: Call Set-up icons

Icon	Description
((([0])))	Incoming call One to three green "circles" intermittently shown
((([.]))	Outgoing call One to three blue "circles" intermittently shown

Table 5: Call Conversation icons

Icon	Description
((([.]))	Call in conversation Call set-up by this phone
	Call in conversation Call set-up to this phone
0	Loudspeaker on
@	Microphone muted while loudspeaker on
	Microphone muted while loudspeaker off

Dialogue mode

In Dialogue mode, the dialogue area displays dialogues regarding missed calls (see <u>Figure 8</u>), messaging, menu settings, warnings and so on (see for some examples).



Figure 8: Examples Dialogue mode

Menu mode

In Menu mode, the dialogue area displays the menu icons or menu sections (tabs) and the specific menu items. E.g.:



Figure 9: Main menu and General setting menu

Edit mode

In Edit mode, you can use the dialogue area to enter and edit digits (e.g., for numbers) and text, e.g., for contact information editing:



Figure 10: Contacts name and number editing

<u>Table 6</u> shows the key to press to insert letters, numbers or symbols.

Besides the physical keys also the Symbol soft key is used in the Edit mode to insert (symbol) characters.

Table 6: key functions in text mode

Key	Uppercase	Lowercase	
1	1.!?,-"@+::	1.!?,-"@+::	
2	ABC2ÆÀÁÂÄ ÅÇ	a b c 2 æ à á â ä å ç	
3	DEF3ÈÉËË	def3èéêë	
4	GHI4ÍÎÏ	ghi4íîï	
5	JKL5	j k l 5	
6	MNO6ŒÓÔÖØ	m n o 6 œ ó ô ö ø	
7	PQRS7Šß	pqrs7šß	
8	T U V 8 Ù Ú Û Ü	tuv8ùúûü	
9	W X Y Z 9 Ÿ Ž	w x y z 9 ÿ ž	
0	(space) 0	(space) 0	
*	*	*	
#	Toggle character case: Abc \rightarrow ABC \rightarrow abc \rightarrow 123		
Symbol	.,`?!"-()@/:_;+&% *=<>£ (space)\$¥° []{}\~^; {; # ''		

Soft key line

Soft keys appear below the handset dialogue area. The key functions change automatically according to the operational state of the handset.

Used notation in this manual



Main menu icons are used to indicate selection of the appropriate menu.

To select the appropriate main menu item use the **NAVIGATION** keys.



Off-white box with text indicates a selected menu item.

To select the appropriate menu item use the **UP** and/or **DOWN NAVIGATION** key.



White box with dark blue top containing text indicates some text or number needs to be given.

To supply the necessary information use the keypad and the **NAVIGATION** keys.



Dark box with question mark indicates a question that the user needs to answer to.

To supply the answer use the appropriate soft key.



Press the indicated key.

.....

The blue box with text indicates a soft key.







The three icons are special soft keys (available in the idle state).

Select the appropriate soft key to execute the indicated action:

_

Left soft key

-

Middle soft key



Right soft key



Use the keypad and/or the **NAVIGATION** keys to enter or change a number, date, name or text:

- Use the keypad to insert one or more digits (0-9, * and #) or characters
- To delete a digit or character use soft key Clear
- Use the Navigation keys to move the cursor to the insertion point
- Use the Up or Down Navigation key to increase or decrease the value of the selected field



Use (one of) the NAVIGATION keys



Use LEFT and/or RIGHT NAVIGATION key



Use UP and/or DOWN NAVIGATION key.

n Press (soft) key displayed one or more times

Optional step(s):

The following step(s) is (are) optional (and marked by a blue line), i.e.,

- they can be skipped by the user OR
- they are not offered to the user.

Used when the following actions (steps) depend on some condition. The condition is preceding the arrow, and the next action to be taken is marked by the indicated number (here: 1).

All actions belonging to set of actions to be taken, are marked by an orange line at the beginning of the actions.

General functions

Switching the handset on

1.



Switching the handset off

> 3s

- 1.
 2.
- ...
 - Yes

Key lock

Attention: You can dial 911 and 112 when the key lock is active. The key lock does not affect the **SOS** key.

Locking

- 1.
- 2.

Also automatic keypad lock can be set from the Settings menu.

Unlocking

- 1.
- 2.

Also automatic keypad lock can be set from the Settings menu.

Call features

Make a call

Dialling a number

1.




2.



Enter/edit: Number

Using Predial mode

1 . (2 NO 3 OF) . (4 NO)



2.

Using Central or Private Directory¹

1. 🚳 Or 🔼

Optional step(s):

2. | 1501 200 307 | 1501 5 K, 6 He | 700 6 K | 9 He | 1501 5 K | 1

Enter the first character(s) of the required name

3.
 4.



Select: required contact

Optional step(s):

5.

Select: appropriate number

6. Or

¹ Central Directory is only available if it is provided by your communication system or using the Central Directory Access tool.

Calls features

Using Speed dial

1. 0 9 wxyz

Or Long press

Making an emergency SOS call

See also Configuring emergency or SOS calls (page 101).

Making an emergency Mandown call

See also Configuring Mandown calls (page 103).

To make a call: the handset needs to remain in the horizontal position for longer than the defined time.

Making an emergency Pull Cord call

See also Configuring Pull Cord calls (page 109).

To make a call: the pull cord needs to be removed from the handset for longer than the defined time.

Answering a call

Answering a call in Normal mode

1. Loudspeaker off

Or

1. Loudspeaker on

Answering a call using any key

See also Answer mode configuration (page 95).

1. Loudspeaker off

Or

Calls features

1. s

Loudspeaker on

Auto-answering mode

See also Answer mode configuration (page 95).

To answer an incoming call no manual action is required.

Muting the ringer of an incoming call

Silent

Rejecting an incoming call

Reject

Change settings during a call

Adjusting the headset or loudspeaker volume

Volume up:



Volume down:



Adjusted volume setting is saved for future calls.

Using mute during a call

Deactivate the microphone (mute)

1. Mute

Activate the microphone (unmute)

Unmute

Activate and deactivate the loudspeaker (toggle function)

1.

Using the loudspeaker enhances the possibility that the speech is distorted. Therefore your DECT handset is no substitute for a conference device!

Transferring a call

Dialling second destination then transfer

- 1. 2.

Enter/edit: Number

Optional step(s):

- 3. Await answer
- 4.

Using Private or Central Directory then transfer

- 1.
- 2.



Central directory

3. Select

Optional step(s):`

4. οк

Enter the first character(s) of the required name

- 5.
- 6.



Select: required contact

Optional step(s):

7.

Select: appropriate number

8. Or

Optional step(s):

- 9. Await answer
- 10.



Calls features

Shuttle the call

To alternate between the two parties (before transfer):

1.

Calls list

Table 7: Call type icons and Call type tabs

	Call Type		
Call List	Icon	Tab	
All calls	-	All calls	
Answered calls		Answered calls	
Dialed calls	•	Dialed calls	
Missed call (unanswered or rejected)			
Missed call (Caller filter)	<u>.</u>	(One combined list)	



Figure 11: Call lists

Calls list

Actions on the calls lists


Open Calls list





2.






Checking the details of a call

n

Open Calls list:











1.




Select: required entry

- 2. View
- 3.

Dialling the number of the call list entry

Open Calls list:











1.



Select: required entry


2.



Or

Call


First edit then dial the number of the call list entry




Enter/edit: Name

6.7.

Calls list




Add a number to an existing contact



Calls list

Transferring a number to the caller filter list









1.



Select: required entry

- 2.
- Select 3.

Save in caller filter

4.

Select

Optional step(s):

5.



Enter/edit: Name

6.

7.

Yes

8.




Deleting an entry

Open Calls list:









1.



Select: required entry

- 2.
- More 3.



Delete item

- 4. 5.
- Select Yes

6.



Missed calls list entries will also be deleted from the list if:

- You answer a call from the to the entry related number (entry moved to the **Answered** calls list).
- You dial the to the entry related number (entry moved to the **Dialed** calls list).


Deleting all entries




Contacts

Contacts

Adding a new contact



Optional step(s):



Note: Currently set value is marked by a blue dot ()

19. n

Changing information of a contact

- 1. 2.

Select: required contact

3.

Continue as in Adding a new contact (page 40) from step 5.

Deleting a contact

- 1.
- 2.



Select: required contact

Contacts





6.

Yes

n

Speed dial feature

See also Using Speed dial (page 29).

Attention: Only the first number in the "chain" Work, Mobile, Home and Other assigned to the contact will be used by the **Speed dial** key.

Adding, replacing or deleting a speed dial contact







Select: required contact

3.







Select

Speed dial

5.



6.





#: John McLean

 \rightarrow **0** add



→ **3** delete

add 0

7.



8.



0 replace

7.



8.



delete €

7. 8.



 $^{^{3}}$ # = 2 .. 9, L1, L2, L3 or L4

Adding contact to the caller filter list

1. 2.





Select: required contact

3. Select

4.



Save in caller filter

5.







Yes

7.



Normal, urgent and emergency messages

The system differentiates between **Normal**, **Urgent** and **Emergency** messages.

Note: It is not possible to send an **Emergency** message from your DECT handset.

Normal messages

The melody assigned to **Notification normal** plays when you receive a normal message. If you receive a normal message during a call, a short alert tone sounds.

Urgent messages

The handset shows urgent messages immediately on the display.

The melody assigned to **Notification urgent** plays when you receive an urgent message. The ringer volume increases to the maximum during the signaling process. If you receive an urgent message during a call, a repeated short alert tone sounds.

Emergency messages

The handset shows emergency messages immediately on the display.

The melody assigned to **Notification emergency** plays when you receive an emergency message. The ringer volume increases to the maximum during the signaling process. If you receive an emergency message during a call, a repeated and in volume increasing short alert tone sounds.

Confirming receipts

You must confirm the receipt of urgent and emergency messages. If you do not confirm the message within 60 seconds, the initiator receives a message that indicates the message was not delivered.

To confirm:

Positively: Or OK

Negatively: Or Reject

Message list full



Attention:

If the display shows this warning no new message can be received. Delete some messages or change the **Overwrite old** setting to **On** – see Message settings (page 53).

Message Menu Sections

The **Messaging** menu contains a number of sections:

Table 8: Messaging Menu Sections

Description	Section
New and draft	New and draft
Inbox	inbox
Sent messages	Sent messages
Settings	Settings

Open Message menu section

- 1. 2.

- 3.
- Select
- 4.













Actions on the messages

Reading a message

Open Message menu section:









1.



Select: required message

2.

Select

Optional step(s):

- 3.

Scroll the text

4.



n

Writing and saving a new/draft message



1. New Or



Select

Select: required message

2.



1b.

3.



Yes

5.

n

Writing and sending a new/draft message

Open Message menu section:

1. New Or 1a.



Select: required message

1b.





3.







5. Select









Forwarding a message

Open Message menu section:



1.



Select: required message

- 2.
- 3. More
- 4



Forward

Optional step(s):

5. 100 2 AUC 404 5 AL 7 FORB 8 TOV





6. Continue as in Writing and sending a new/draft message (page 48) from step 3.

Replying to an incoming message

Open Message menu section:



1.




Select: required message

- 3.
- Reply



4.





6.

Select

Optional step(s):

- 7. ок
- 8. n

Deleting a message







1.



Select: required message

- 2. Select
- 3.



Delete message

- 4.
- Select 5.

Yes

6.



Deleting all messages

Open Message menu section:









- 1. More
- 2.



Delete all messages

- 3.
- 4.



Select





5.



Saving sender to the contacts list

Open Message menu section:



1.



More

Select: required message

- 2.
- 3.



Save as contact

- 4. Select
- 5. Continue as in <u>Transferring a name/number to your contacts list (page 35) from step 5.</u>

Add sender to existing contact

Open Message menu section:



1.



Select: required message

- 2.
- 3.




Add to contact

- 4. Select
- 5. Continue as in Add a number to an existing contact (page 37) from step 5.

Message settings

The following messaging options can be configured to **On** or **Off**:

- Overwrite old to control what happens when the handset receives a new message, but there is no room to store more messages:
 - On: the oldest message stored on the phone is overwritten
 - Off: new message is not stored. An Urgent or Emergency message is shown on the display; a Normal message is rejected.
- **Sent messages** to control whether sent messages are stored in the handset **(On)** or not **(Off)**.
- **Display** to control whether **Normal** messages are displayed immediately upon receipt (**On**) or not (**Off**).
- Auto answer msg Please contact your System Administrator
- Silent answer msg Please contact your System Administrator



Open the Calendar

- 1. 2.



3.

Select

Changing the calendar format (week or month view)

Open the Calendar

- 1.
- Select 2.

View week View month

- 3. 4.
- n

Select

Open schedule for today

Open the Calendar

- 1. 2.
- Select

Select



- 3.
- 4. View

Open schedule for a given date

Open the Calendar

More

- 1.
- 2.



Go to date

- 3. Select
- 4

15 - 01 - 2013

- 5. Select
- 6. View


Adding an appointment


Open the Calendar

- 1.
- Add 2. 16 - 01 - 2013
- 3.
- Save 4. 11 : 00
- 5. Save
- 6. 15 minutes 30 minutes 1 hour 2 hours 4 hours

Other

- 0
- 7. Select Go to step 12.






Open appointment

Note: Days with appointments will be marked with a red dot at the bottom right of the date.

Open the day/date of the appointment using <u>Open schedule for today/Open schedule for a given date</u>



Editing an appointment

Open appointment

- 1. Edit
- 2. Make the necessary changes like in <u>Adding an appointment (page 56)</u> from step 2.

Copying an appointment

Open appointment

- 1.
- 2.



- 3. Select
- 4. Make the necessary changes like in <u>Adding an appointment (page 56)</u> from step 2.

Deleting an appointment

Open appointment

- 1. More
- 2.

Delete

- 3.
- 4. Polete appointment
 - Yes

Select

5. • 1

Additional features (Accessories)


Calculator

When the **Calculator** is selected the following holds:



used to insert a decimal point used to make a percentage of the given entry change the use of the **NAVIGATION** keys between:

- Mathematical operators
- Moving the cursor to the insertion point



Stopwatch



Use of the stopwatch soft keys:

Table 9: Stopwatch soft keys

Soft key	Description
Start	Start a new measurement Or Continue a stopped measurement
Stop	Halt the measurement
Lap	Save the intermediate result and continue the measurement
Reset	Reset the stopwatch (back to 0)

Alarms (alarm clock)

Open Alarms

- 1. 2.

Alarms

- 3.
- Select
- 4.
- 5. Select

Assigning or change a daily alarm

Open Alarms

- 1.

Select



Assign new Change existing

- 2.
- 3.



- 4. Save
- 5. n

Turning off a daily alarm

Open Alarms

1.





- 2. Select
- 3. Turn off

4. n n

Assigning or change a recurrent alarm

Open Alarms








4. Save

For the required days of the week:



Note: (Already) selected days are marked with 🗹

Turning off a recurrent alarm

Open Alarms



- 2. Select
- 3. Turn off
- 4. n

Setting snooze time

Open Alarms

1.



Snooze time 10 minutes

2.





Note: Currently set value is marked by a blue dot ()

4. Select

5.



The **Settings** menu contains a number of sections:

Table 10: Settings Menu Sections

Description	Section
General	General
Sounds - normal	Sounds - normal
Sounds - silent	Sounds - silent
Display	Pisplay
Calls	信 Calls
Connectivity	Connectivity

Open Settings menu section

- 1.
- 2.



- 3.
- 4.




















General settings

Table 11: General setting

Item	Description	Page
Silent	• Switch to/from the silent "profile"	<u>67</u>
	Set the current Time & date	<u>67</u>
Language English	Set the Language	<u>70</u>
Shortcuts	• Create Shortcuts to the handset menus and features (by pressing a navigation key)	<u>70</u>
• LED signal	Assign a certain condition to one of the three LEDs	<u>71</u>
Security	Set the security settings: Phone lock, Automatic keylock, PIN Code and Proxy password	<u>72</u>
Handset name Empty	• Set the Handset name	<u>75</u>
₹ RFID	• Set the RFID settings: Notification, Destination and Out of LF	<u>75</u>
Reset settings	 Return settings to the factory values. Not affected are: Contacts, PIN Code, Proxy password and the system registrations 	<u>77</u>



View handset information


77

Setting Silent

If **Silent** is **On** the handset uses the sound definitions set with the Sounds - silent settings, otherwise it uses the Sounds - normal settings.

On

Open Settings menu section:



3.

Ouickly toggle **Silent** setting:

1. Long press

Setting the time and date

Note: If your communication system provides the date and time, then setting the date and time has only a temporary effect and will, in due time, revert to the by the system provided time and date.

Setting the time

Open Settings menu section:



2. Select



4. Select



Optional step(s):





Note: Currently set value is marked by a blue dot (
)

- 8. Select
- 9. Save
- 10. n

Setting the date





2.

1.

- Select 3. Date 22-01-2013
- 4.



Optional step(s):


6. Format 7.



Note: Currently set value is marked by a blue dot ()


- 8. Select
- 9. Save
- 10. n


Setting the language



Configuring shortcuts

Shortcuts are used to get quick access to menu items.






Configuring the LED signal


n

7.

The Red LED, Green LED and Yellow LED can be used to indicate certain conditions to the user:

- Missed call
- **Text message**
- Voice message
- Text or voice msg
- Low battery
- Charging
- **Silent charging**






Note: Currently set value is marked by a blue dot ()

- 6. 7.
- e n

Security options

Setting the Phone lock feature

If the **Phone lock** is set then upon turning on your handset you'll be asked to enter the **PIN Code**.



Setting the Automatic keypad lock feature

Open Settings menu section:



1.



2. Select

3.



Automatic keylock

4.

1.





6. Select

7. **n**

Changing the PIN code

Open Settings menu section:



1.





2.





Change PIN code

4.









6.

ок








- 10.
- 11. **n**

Changing the Proxy password

Change the **Proxy password** that is used at SIP authentication.

Open Settings menu section:









- 10. ок
- 11. n

Defining the handset name







Select



- 2.
- 3.
- 4. Save
- 5. n

RFID Options

An optional DLA (DECT Location Accessory) module can be inserted in the I766 behind the clip. The DLA is able to receive the LF signal of a beacon and when an alarm is initiated on the handset, the alarm message will be provided with the beacon identity.

Setting the RFID notification feature

Open Settings menu section:







- 2.
- 3.

4.

Assigning an RFID destination number

Open Settings menu section:



1.



RFID

- 2.
- 3.



Select

Number


- 4.
- 5.



Select



- 0 Lookup contact
 - 6. 7.
- Select



- 8. Select
- 9.




- Enter number 0
- 6.
- Select 7.

n




When no number is entered then the **Emergency call** feature is disabled

- 8.
- 9.



Setting the RFID Out of LF feature



Resetting settings

All user determined **Settings** are set to the default factory

values! Open Settings menu section:





- 2. Select
- 3. (and 5.4) (an



- 4. Yes
- 5. 100 2.00 300 404 5.4 600 7/00 81W 9000 * 0 8



- 6. ок
- 7. 📭 n

View status information

Open Settings menu section:



1.





- 2. Select
- 3.





Note: In reality divided over three screens

- 4. ок
- 5. **n**

Sounds (normal & silent) settings

Table 12: Sounds settings


Item	Description	Page
incoming call	 Sound settings related to an Incoming call: Ring volume Ring external melody for calls from an external source Ring internal melody for calls from an internal source Ring unknown call melody for calls from an unknown source Group ring melody for calls from an group source Intercom ring melody for calls from an intercom source Emergency ring melody for calls from an emergency call source ARB ring melody for calls from an automatic ring back source Increasing ring to determine whether the Ring volume increases gradually Vibrator to define the trembler feature for calls 	81
Message notification	Sound settings related to an incoming message ⁹ : • Notification volume	83

Table 12: Sounds settings

Item	Description	Page
	 Notification normal melody for Normal messages Notification urgent melody for Urgent messages Notification emergency melody for Emergency messages Increasing notification to determine whether the Notification volume increases gradually Vibrator to define the trembler feature for messages 	
Alerts	Sound settings related to Alerts (for Calendar and Alarms): • Alert volume • Alert melody • Increasing alert to determine whether the Alert volume increases gradually • Vibrator to define the trembler feature for Alerts	<u>86</u>
Feedback	 Sound settings related to: Key sound for the sound that occurs when you press a key Confirmation sound for the sound that indicates successful setting 	<u>88</u>
∆ Noise reduction	Configure the settings for Noise Reduction	90

Incoming call

Setting the ring volume



Ring internal

Melody n

Ring unknown call
Melody n

Or

4. Select



5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

- 6. 7.
- Play Stop
- 8. Select
- 9.



Setting the increasing ring feature

Open Settings menu section:



Or



1.



Select

(§) Incoming call

- 2.
- 3.



....

Increasing ring

4.

Or

On

5. **n**

Setting the vibrator feature

Open Settings menu section:



Or




1.



(§) Incoming call


2.

Select



Message notifications

Setting the notification volume



7.



Setting the notification melodies





Or



1.



Message notification

- 2.
- 3.



Select



Melody n

Or

Or

- 4.
- 5.





Note: Currently set value is marked by a blue dot ()

Optional step(s):

- 6.
- Play Stop
- 7. 8.
- Select
- 9.



Setting the increasing notification feature

Open Settings menu section:







1.



Message notification

2.

Select





4.

Or

On

5.



Setting the vibrator feature

Open Settings menu section:



Or



1.



Message notification

2.



4.





Select



Vibrate and ring

Note: Currently set value is marked by a blue dot (
)


6. Select

7.




Alerts

Setting the alert volume



Setting the alert melody





5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

- 6. 7.
- Play Stop

Select

- 8.
- 9. **n**

Setting the increasing alert feature

Open Settings menu section:



Or



1.



Select

△ì Alerts

- 2.
- 3.



On

- 4.
- Off
- Or



n

Setting the vibrator feature

Open Settings menu section:



Or



1.



▲ Alerts

2.



Vibrate then ring


✓ Vibrate only✓ Vibrate and ring

Note: Currently set value is marked by a blue dot (●)


- 6. Select
- 7. **n**

Feedback

Setting the key sound feature



Setting confirmation sound



- 2.
- 3.



- 4. Off
- Or On
- 5. • n

Setting the coverage warning feature

Open Settings menu section:





1.



- ? Feedback
- 2. Select
- 3.



- Or On
- 5. n

Setting the charger warning feature

Open Settings menu section:



Or



1.

4.







Feedback

4.



Or




5. n

Noise Reduction

In environments with a lot of ambient noise, such as in production environments, the I766 noise reduction feature can be enabled resulting in a strong reduction of the noise level. The I766 has an additional microphone situated at the top back of the handset, by comparing the audio from both microphones, the I766 can discriminate voice and ambient noise. This results in less disturbance of the call and much better quality of the voice.

Setting the noise reduction feature



Display settings

Table 13: Display settings

Item	Description	Page
⊌ Wallpaper 	Select the image that is displayed on the screen of your handset in the idle state	<u>91</u>
Startup screen	Select the startup screen image which displays temporarily when the handset starts	92
Power save xxsec. / yysec.	Configure the periods of time after which the handset's display is dimmed and turned off	92

Selecting Wallpaper

For other Wallpaper than Default: Please contact your System Administrator

Open Settings menu section:



1.





- 2. Select
- 3.





Note: Currently set value is marked by a blue dot (

)

Optional step(s):

- 4.
 5.
- View
- 6.
- Select

7.



Selecting startup screen

For other Startup screen than Default or NEC: Please contact your System Administrator

Open Settings menu section:







- 2.
- 3.



Note: Currently set value is *marked by a blue dot* ()

Optional step(s):

Select

- 4.
- View 5.
- 6. Select
- 7. n

Configuring power save


The display of your DECT Handset has three intensity levels:

- Display on;
- Display dimmed;
- Display off.



Figure 12: Display intensity levels On, Dimmed and Off

The various levels are used to save energy and are applied based on the **Power save** setting.




Calls settings

Table 14: Calls settings

Item	Description	Page
Units h:mm:ss nn	View information regarding outgoing Call time and Message count.	<u>95</u>
Answer mode	 Determine how incoming calls can be answered: Normal using Or By pressing Any key Automatically (Auto answer) 	<u>95</u>
Caller filter	Selectively block or accept calls from specified callers.	<u>96</u>
Emergency Call	Configure the Emergency call feature to dial a number or send a text message by long pressing the SOS key.	<u>101</u>
Silent charging	Determine what action is taken when the handset is called while in the charger.	115
Missed call time nn sec.	Determine when a not answered call is added to the Missed calls list	<u>116</u>

Table 14: Calls settings

Item	Description	Page
Voicemail number Empty	Configure the Voicemail number	<u>116</u>




Answer mode configuration



2. Select








Caller filter configuration

Adding an entry to the Caller filter list



Select


9.






11. n











Continue as in Adding an entry to the Caller filter list (page 96),

- Enter number, from step 8

Deleting an entry from the Caller filter list

Open Settings menu section:



1.



Caller filter

- 2.
- 3.




Select

List

- 4. Select
- 5. More
- 6.

Delete

- 7. Select
- 8.



- 9.
- Select



Yes

11.



Deleting all entries in the Caller filter list

Open Settings menu section:



1.



Caller filter



3.



List

- 4.
- Select
- 5.6.



Delete all

- 7. Select
- 8.



9.



Yes



- 10.
- ОК
- 11.



Activating Caller filter

Open Settings menu section:



1.





- 2.
- Select
- 3.



Mode

4.

Select

5.



Block list


- → Accept only calls from callers in the Caller filter
- → Don't accept calls from callers in the Caller filter
- Filter off
- → Caller filter not used

Note: Currently set value is marked by a blue dot (♠)

- 6. Select
- 7. **n**

Configuring emergency or SOS calls

Assigning emergency call number



- Lookup contact
- 6.7.



Select: required contact

- 8. Select
- 9. **n**

2 Enter number

- 6. Select
- 7. (100 2 ACC 3 ACC 4 AC

Save



When no number is entered then the **Emergency call** feature is disabled

- 8.
- 9. **•** n



- 6. Select
- 7. Enter the first character(s) of the required name
- 8.
- 9.



n

ок

Select: required contact

- 10. Select
- 11.

Assigning an emergency message

Open Settings menu section:



1.



- 2. <u>Sele</u>ct
- 3. Message
- 4. Select
- 5. To make a voice call no Emergency call message should be defined.
- 6. Save
- 7. n

Configuring Mandown calls

Activating Mandown and assigning a call number

Open Settings menu section:



1.






- 2.
- Select 3.





- 4. Select
- 5.




→ 6 Central directory







Activating Mandown and assigning a message



- Lookup contact 0
- 6.
- Select 7.

Select: required contact

- 8. Select
- 9. n
- Enter number 0
- 6. Select
- 7.
- 8. Save
- 9. n
- 6 Central directory Select
- 6.
- 7.

Enter the first character(s) of the required name

- 8.
- 9.



οк

Select: required contact

- 10. Select
- 11. n

12. Message

13. Select

15. Save

16. Man down Off

17. Select


18. Mode Message

19. Select 20.



21. select 22. n

Setting the Mandown Auto Answer option





On

8. Select

9. **n**

Setting the Mandown Delay and Prealarm time






- 8. Select
- 9. **n**

Configuring Pull Cord calls

Activating Pull Cord and assigning a call number







6.

7.

Select: required contact

8.

9.

Enter number 2

6.

7.

Select



8.

9.

6 Central directory

6. 7.



Enter the first character(s) of the required name

8. 9.





Select: required contact

10. Select

11.







- 13. Select
- 14. Mode Call
- 15. Select



- 17. Select
- 18.

Activating Pull Cord and assigning a message



- 4. Select
- 5. Lookup contact \rightarrow 1

 Enter number \rightarrow 2

 Central directory \rightarrow 3

- Lookup contact
- 6. 7.
- Select

Select: required contact

- 8. Select
- 9. 📑 n
- **2** Enter number
- 6. Select
- 7. (100 2 acc 3 av 4 in 5 in 6 in 9 acc 7 (60 8 in 9 acc
- 8. Save
- 9. **n**
- 6 Central directory
- 6. Select
- 7. Enter the first character(s) of the required name
- 8. ок
- 9. Select: required contact
- 10. Select
- 11. 📭 n

12. Message

- 13. Select
- 15. save
- 16.

 Pull cord
 Off
- 17. Select
- 18. Mode Message
- 19. Select
 20. Message
- 21. select 22. n

Telephone settings Setting the Pull Cord Auto Answer option

Open Settings menu section:



1.



2. 3.



7 Pull cord

4.





Select

Auto answer

6.





Select

On

8.

9.



Setting the Pull Cord Delay and Prealarm Time

Open Settings menu section:



1.





2. 3.



Pull cord

4. Select



→ Disconnect from the


charger¹⁴

charger

system while in the

→ Turn off the ringer (and

vibrator) while in the



¹⁴ If configured: redirect call to alternative destination

Disconnect

Silent

Note: Currently set value is marked by a blue dot (●)

- 4. Select
- 5. **n**

Defining the missed call time

Open Settings menu section:



1.



- 2.
- 3. (10) 200 307 601 57. 600 700 800 900 • 0 0

Select

- 10 Save
- 4. Save
- 5. n

Voicemail

Use the Voicemail feature to listen to voice messages left by calling parties¹⁵. You receive a voicemail in the following situations:

- a. if your handset is switched off
- b. if your handset is busy
- c. if your handset is out of the coverage area

A new voice message dialogue appears only once, i.e., when a caller leaves a first new message in the mailbox. A voicemail

¹⁵ Your communications system needs to support the Voicemail feature

symbol () appears in the icon line; it disappears after you play the message.

Assigning the Voicemail number





1.



- 2.
- 3. \$\frac{1 \times 2 \times 3 \times 0 \times 0
- 4. Save

Select

5. **n**

Connectivity settings

Table 15: Connectivity settings

Item	Description	Page
Register	 Register handset to a DECT system Please contact your System Administrator 	-
Deregister	Remove registration your handset from a DECT system Please contact your System Administrator	-
Network select	Select which DECT system is to be used (only if the handset is registered to more DECT systems)	118
§ Bluetooth	Enable/Disable Bluetooth connectivity for pairing a Bluetooth headset.	<u>119</u>

DECT system selection

Open Settings menu section: 1. Network select

NEC Hilversum

2. Select

3. Auto. select

→ Handset selects DECT system automatically

→ Select: required DECT system (here e.g., NEC Hilversum)

Note: Currently set value is marked by a blue dot (♠)


- 4. Select
- 5. **n**

Bluetooth settings

Table 16: Bluetooth headset status

Icon	Description
8	Connected
8	Disconnected
(B	In conversation

Enable Bluetooth





5.



6.



7.



Disable Bluetooth

Open Settings menu section:



1.



Bluetooth

2.





Select

Select

Enable/disable Enabled

4.





6.



7.



Pairing a Bluetooth headset

Open Settings menu section and Enable Bluetooth:



1.



- 2. Select
- 3. Start pairing mode on your Bluetooth headset refer to your headset documentation.
- 4.



Search for devices

5. Select

6.





Select: required headset (e.g. BT 31R)

7.

8.



Pair



Headset PIN Code!

- 8. ок
- 9.

n

Connecting a paired Bluetooth headset

Open Settings menu section:




1.




Bluetooth

2. Select



Disconnecting a paired Bluetooth headset



Renaming a paired Bluetooth headset









Bluetooth

- 2.
- 3.



Select

Paired devices

- 4. Select
- 5.



BT 31R

Select: required headset (e.g. BT 31R)

- 6.
- 7.



Select

More

Change name

- 8.
- 9.







- 10. Save
- 11. n

Retrieve information for a paired Bluetooth headset


Open Settings menu section and Enable Bluetooth:



1.



Bluetooth



Delete a paired Bluetooth headset

Open Settings menu section:





2. Select

10.

11.

οк

n







Paired devices

- 4.
- 5.

Select

More

BT 31R

Select: required headset (e.g. BT 31R)

- 6.
- 7.
- Delete
- 8. Select
- 9.



- 10. Yes
- 11. n

Delete all paired Bluetooth headsets

Open Settings menu section:



1.



Bluetooth

- 2. Select
- 3.



Paired devices

- 4. Select
- 5.

Select: required headset (e.g. BT 31R)

- 6. Select
- 7.

Delete all

- 8. Select
- 9. Bluetooth

 ?
 Delete all forms in the let?
- 10. Yes
- 11. 📭 n

THIS PAGE IS INTENTIONALLY LEFT BLANK	